



VAIO Batteries and AC Adaptors



VGP-BPS21 5000mAH (= VGP-BPS13)
VGP-BPL21 7500mAH (= VGP-BPL13)



VGP-BPS24

****Too many batteries to list, send us an email regarding your unit.**



VGP-AC10V10
10.5V / 5V 3.8A
USB Socket built in.



VGP-AC19V36 or 19V41
19.5V 4.7A
Looks after 19V13, V14, V19, V20,
V26, V27, V28, V31, V32, V33,
V34, V35, V36, V37, V41 & V43

Power Cord
ACL112



Power Cord
PLD557
Or
ACL112



****Too many AC adaptors to list, send us an email regarding your unit.**

Need a Sony camera battery?

V series



NP-FV50 980mAh
NP-FV70 1960mAh
NP-FV100 3900mAh

M series



NP-FM30
NP-FM50
NP-FM70
NP-FM90
NP-FM91
NP-QM71D
NP-QM91D
NP-FM55H
NP-FM500H

N series



NP-BN1

W series



NP-FW50

D series



NP-FD1

L series



NP-F330
NP-F550
NP-F570 2100mAh
NP-F770 4400mAh
NP-F970 6600mAh

H series



NP-FH30
NP-FH50
NP-FH60
NP-FH70
NP-FH100

X series



NP-BX1

Y series

NP-BY1



G series



NP-BG1
NP-FG1

K series



NP-BK1

Sony AC Power Supplies for Handycams and digital cameras

Refer to your Sony Handycam instruction manual to select correct AC adaptor for you camera.

ACLS5



A, F, P SERIES
8.4V 1.7A

ACL200



H & V SERIES
8.4V 1.7A

ACL10/15, ACL100



M & L SERIES
8.4V 1.7A

ACUB10

For HX, TX & WX digital camera series

5V 0.5A

*USB cable required



Power Cord
for AC adaptors

PLD557



Sony Battery Chargers

BCCSG



NPFG1 BATTERY CHARGER
"G" SERIES

BCCSD



NPFD1/NPFR1/
NPFT1/ NPFE1/
NPBD1 BATTERY CHARGER
"D" "R" "T" "E" SERIES

BCVH1

Discontinued see BCQM1



NPFH30/40/50/60/70/
100 BATTERY CHARGER
"H" SERIES

BCCSN



NPBN1 BATTERY CHARGER
"N" SERIES

BCVW1



NPFW50 BATTERY CHARGER
"W" SERIES

Power Cord
for Chargers
PLD557



Sony Multi Battery Charger



- Handycam battery charger
- Quick Charging Function
 - Multi compatible for five different series of battery
 - USB AC Adaptor function (1.5A)
 - For V, W, M, H & P battery series

BCQM1



- Digital camera battery charger
- Quick Charging - Capable of charging in just 1.5hrs
 - Multi compatible for seven different series of battery
 - USB AC Adaptor function (1.5A)
 - For X, N, G, D, T, R & K battery series

BCTR X



Power Cords

PLD557

Australian Fig 8 cord.
1.8meters



PLD557-US

Going to America?
US Fig 8 with flat side to suite
Sony battery chargers, etc
Grey in colour.
1.8meters




ACL112

Australian Clover IEC C5 cord
1.8meters



ACL112-US

Going to America?
US clover IEC C5 to suite
Sony laptop ac adaptors, etc
1.5meters



PLD559

Australian IEC C13 cord.
1.8meters



Universal charge to suite your camera battery!!

The DDCC1 charger has a dedicated battery plate to suite your battery. It is fully automatic and will safely charge up the battery then terminate charging when the battery is fully charged.

Suits the newer type cells as used in digital cameras and video camcorders.

Not suitable for Ni-Cd or Ni-MH.

This system includes an AC cable for the home and a DC charger cable for in the car.

This charger requires a adaptor plate to suit your particular battery (see list below).

For more info, just email or give us a call.



Sony Battery:

NP-BD1, NP-FD1, NP-FR1, NP-FT1

-- Order **DDCC1AVP113**

NP-BK1

-- Order **DDCC1AVP152**

NP-BG1, NP-FG1

-- Order **DDCC1AVP181**

NP-BN1

-- Order **DDCC1AVP351**

NPFH100, NPFH30, NPFH40, NPFH50,
NPFH60, NPFH70, NPF50, NPF70, NPF71,
NPF90, NPFV100, NPFV50, NPFV70, NPFV90

-- Order **DDCC1AVP55**

NPF330, NPF530, NPF550, NPF570, NPF730,
NPF750, NPF770, NPF930, NPF950, NPF960,
NPF970, NPFM30, NPFM50, NPFM500H, NPFM51,
NPFM55H, NPFM70, NPFM71, NPFM90, NPFM91,
NPQM50, NPQM51, NPQM70, NPQM71, NPQM90, NPQM91

-- Order **DDCC1AVP550**

NP-FA50, NP-FA70

-- Order **DDCC1AVP555**



★ If you have a Canon, Sony, Panasonic, Sharp, Sanyo, Samsung, Olympus, Pentax, Fujifilm, JVC & Kodak Battery we could have the charger for you! Just email your battery details and we can try to match it up for you.