

# Remote Tester

## Universal Remote Control Tester

IR remote tester is to test the IR signal from your remote control for your TV, air conditioner, sound system, etc. Just point and press the buttons on your remote and the LED indicator will tell you whether the buttons are working.

## REMTEST

